

# **EVOCHARGE**

# EVOCHARGE<sup>®</sup> WITH EVOREEL<sup>®</sup> Charging Stations (EVSE, iEVSE, iEVSE Plus)

## Installation Guide & User Manual

Revision 1.3



# **IMPORTANT SAFETY INSTRUCTIONS**

This document contains instructions and warnings that must be followed when installing and using the Electric Vehicle Supply Equipment (EVSE). Before installing or using the EVSE, read this entire document as well as WARNING and CAUTION markings in this document.

### Safety Instructions

The symbols used have the following meaning:



WARNING: RISK OF PERSONAL INJURY

WARNING: RISK OF ELECTRIC SHOCK



WARNING: RISK OF FIRE

CAUTION: RISK OF DAMAGE TO THE EQUIPMENT

- The charging station must be installed, adjusted, and repaired only by a licensed electrician.
- Make sure that the materials used and the installation procedures follow local building codes and safety standards.
- The information provided in this manual in no way exempts the user of responsibility to follow all applicable codes or safety standards.
- This document provides instructions for the charging station and should not be used for any other product. Before installation or use of this product, review this manual carefully and consult with a licensed contractor, licensed electrician, or trained installation expert to make sure of compliance with local building codes and safety standards.
- CAUTION: To reduce the risk of fire, connect only to a circuit provided with the minimum branch circuit overcurrent protection requirements in accordance with the National Electrical Code, ANSI/NFPA 70, and the Canadian Electrical Code, Part I, C22.1.

#### Repair and Maintenance Clause

- All EVOCHARGE products do not require routine maintenance however, periodic inspections should be conducted to ensure that all parts remain in good working order and no damage exists. Do not attempt to open, disassemble, repair, tamper with, or modify any components of the products the products are not user serviceable. Contact EVOCHARGE for any repairs.
- Only licensed electricians can repair or maintain the charging station. It is forbidden for general users to repair or maintain it. Turn off input power before performing any repairs or maintenance to the charging station.

#### FCC Declaration of Conformity

- This charging station complies with part 15 of the FCC Rules. Changes or modifications the charging station not expressly approved by the manufacturer could void FCC compliance.
- Operation is subject to the following two conditions: (1) This charging station may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

#### **OVERALL WARNINGS & CAUTIONS**

WARNING: RISK OF ELECTRIC SHOCK

Basic precautions should always be followed when using electrical products, including the following:

- Read all the instructions before using this product.
- This device should be supervised when used around children.
- Do not put fingers into the EV connector.
- Do not uses this product if the flexible power cord or EV cable is frayed, has broken insulation, or any other signs of damage.
- Do not use this product if the enclosure or the EV connector is broken, cracked, open, or shows any other indication of damage.



WARNING: RISK OF ELECTRIC SHOCK

Improper connection of the equipment grounding conductor can result in a risk of electric shock. Check with a qualified electrician or serviceman if you are in doubt as to whether the product is properly grounded.

A

WARNING: RISK OF ELECTRIC SHOCK

- Do not touch live electrical parts.
- Incorrect connections may cause electric shock.

WARNING: This equipment is intended only for charging vehicles that do not require ventilation during charging. Please refer to your vehicle's owner's manual to determine ventilation requirements.

# **Product Features**

#### EVOCHARGE<sup>®</sup> With EVOREEL<sup>®</sup> Electric Vehicle Charging Stations

- J1772 AC Level 2 (208-240 VAC), 24A (5.8 kW) Continuous Output Rated (Per Port) with adjustable Maximum Current Output capability to Support Multiple Circuit Ratings
- EVOREEL<sup>®</sup> with EVOCHARGE Charging Stations:
  - EVOCHARGE EVSE: Standard charging station, non-networked
  - EVOCHARGE iEVSE: True Open Protocol: OCPP 1.6 capable of operating on any OCPP network
  - EVOCHARGE iEVSE<sup>®</sup> Plus: Access Control via RFID Card (Including without Network Connection) & Mobile App; Payment Capability; Remote Monitoring/Control; Demand Response & Local Load Management
- EVOREEL<sup>®</sup> with EVOCHARGE EVSE:
  - o Simple Operation: No user interface required with EVSE, simply Plug-in to your EV to initiate charging
  - Modern, Elegant & Compact Design: EVSE form factor smaller than a standard sheet of letter-size paper
- Robust Construction, Certified for Outdoor Use: Robust, durable design; tamper-resistant features including provision to install a padlock to secure charging station to mount; NEMA 4 certified for outdoor and indoor use
- Cable & Connector Management: EVOREEL Cable Management with Connector Holder
- Charging Station: UL & cUL Listed, File Number: E469990

#### Security and Tamper Feature

In addition to the lock screw that secures the EVOCHARGE iEVSE Plug charging station to the wall mount bracket (Refer to Section 2.3, Note 3., Installing the Charging Station), if desired, a feature is included as part of the charging station and wall mount bracket to install a small padlock for added security and tamper benefits. This feature is located at the bottom of the charging station near the charging station – wall bracket lock screw.

#### Self-Monitoring and Recovery | Power Outage Recovery

When a charging session is interrupted due to a temporary error condition, the charging station will automatically restart charging when the cause of the temporary error condition returns to normal. The status indicator lights remain flashing RED until the error condition is resolved.

- Temporary error conditions include: Over Current, Over Voltage, Under Voltage, and Over Temperature.
- For Over Current (OC) conditions: The charging session will be stop while OC occurs. After recovery from OC for 30 seconds, the charging station will automatically restart charging for three times.
- When charging session stopped due to CCID trip, the charging station will try to restart after 15 minutes for 3 times.

When power resumes after an outage, the charging station restarts automatically with a delay ranging from 120 to 720 seconds. The delay is designed to avoid impacting the utility grid when multiple charging stations are in the same area attempting to resume charging simultaneously.

# **Product Specifications**

### EVOCHARGE® With EVOREEL® Electric Vehicle Charging Stations

Description Specifications				
	SAE J1772; AC Level 2			
EVSE Type	EVOCHARGE EVSE: Standard, Non-network EV Charging Station			
	EVOCHARGE iEVSE: Intelligent, Open Network, OCPP-enabled charging station EVOCHARGE iEVSE Plus: OCPP 1.6 via LTE Cellular Modem, Wi-Fi or Ethernet			
	connection			
Max Output Pating	24A, 5.8 kW Maximum Output			
Max Output Rating	For use with a 40A (or greater) Dedicated Circuit			
Alternate Adjustable Output Ratings	16A or 24A for use with 20A or 30A Dedicated Circuit			
Charge Cable Lengths	Standard: 22 ft. (6.7m); Optional: 30 ft. (9.1m)			
Electrical Circuit / Input Power Requirements	208-240VAC, 50/60 Hz. Circuit Requirement: 40A (or grater) Dedicated Circuit Per Port; Branch Breaker: Double pole; Circuit Conductors: Line 1, Line 2, Earth Ground			
Input Power Connection	P/N: EVO30-111-002: Hardwire, 1" NPT Knockout at Bottom of EVSE P/N: EVO30-101-002: NEMA 6-50P Plug-in (can be removed for Hardwire)			
Charging Station Color	Standard: White			
Installation Rating	NEMA 4, Indoor/Outdoor Rated			
Operational Ratings	Temperature: -22°F to 122°F (-30°C to 50°C); Humidity: 95% RH non-condensing			
Mounting	Wall or Ceiling Mount Installation			
Overall Dimensions	EVSE: 11.0 x 7.5 x 3.2 inches (28.0 x 19.0 x 8.1 cm)			
(HxWxD)	EVOREEL: 13.8 x 12.0 x 9.2 inches (35.1 x 30.5 x 23.3 cm)			
Display & Indicators	LED Charge Status Indicators (Power/Ready, Charging, Fault) & LED Display			
Cable Management	EVOREEL Cable Management with Connector Holder			
Standards & Compliance	EVSE: UL & cUL Listed, File Number: E469990; SAE J1772, UL 2594, UL 355, CSA			

# SAVE THESE INSTRUCTIONS

# **Manual Contents**

1	Introduction & Unpacking7			
	1.1	Unpac	king7	
2	Insta	llation		
	2.1	Before	Installation8	
		2.1.1	Installation Planning & Service Wiring8	
		2.1.2	Grounding Instructions8	
	2.2	Tools 8	& Parts Required for Installation9	
	2.3	Input \	Wiring Connection (Optional for p/n: EVO30-101-002)9	
	2.4	Installa	ation Steps9	
	2.5	Install	the Plug and Cable Holder14	
	2.6	Chargi	ng Status Indicators16	
	2.7	Chargi	ng your Electric Vehicle (EV)16	
		2.7.1	Plug and Charge17	
		2.7.2	Online Authorization17	
		2.7.3	RFID Card Authorization Local and Offline Authorization17	
	2.8	Stop C	harging18	
		2.8.1	Self-Monitoring and Recovery (Auto Restart)18	
		2.8.2	Power Outage Recovery19	
	2.9	Genera	al Product Care and Use Information19	

# **1 Introduction & Unpacking**

This user manual applies to the EVOREEL<sup>®</sup> Charging Stations for use with all Electric Vehicles (EVs) and Plug-in Hybrid Electric Vehicles (PHEVs) sold in North America.

### **1.1 Unpacking**

Unpackage all items and confirm the contents as noted below.




Table 1-1 Box Contents

Item	Description	Qty.	Notes
1	Charging Station with EVOREEL	1	
Ţ	Cable Management System	1	
2	Charging Station Mounting Bracket	1	Bracket is Attached to each Charging Station
3	Connector Holder	1	Holder is packaged within cardboard compartment
			of charging station packaging
1	Mounting Fasteners &	1	All Fasteners and associated hardware required for
4	Related Hardware	set	installation – packaged separately

# **2** Installation

### 2.1 Before Installation 2.1.1 Installation Planning & Service Wiring



WARNING: RISK OF ELECTRIC SHOCK

- Do not touch live electrical parts.
- Incorrect connections may cause electric shock.
- Disconnect the power supply to the charging station and verify no power is present before installing, adjusting, or repairing the charging station. Failure to do so may result in physical injury or damage to the power supply system and the charging station.

The charging station must be installed only by a licensed electrician in accordance with the provisions of the local electrical industry construction and should comply with national electrical codes and standards. Before installing the charging station, make sure you have read these instructions in this manual and fully understand its contents. Appropriate protection is required when connecting to a main panel/switchboard. The tools and parts used as outlined in the section "Tools & parts required for installation".

Prior to installation, locate an available electrical source that can support the following Input Requirements for the Charging Station Per National Electric Code (NEC) requirements:

- For Maximum Output Setting (30A Default Factory Setting), a DEDICATED CIRCUIT FOR EACH PORT rated for minimum 40A; 208-240 VAC, 50-60 Hz, Single Phase must be used. Circuits greater than 40A may also be used.
- A Double Pole Circuit Breaker of the circuit rating must be used. The Charging Unit has a built in GFCI protection; do not provide any additional GFCI protection upstream of the charging unit.



CAUTION: The service wiring in this section are specific to North America only. Before installing the Charging Station, identify the type of utility service connection available onsite. If you have unsure about the type of connection available at the service panel, contact your utility service provider.

Prior to mounting, determine location of an acceptable mounting support. All charging station products must be anchored into a mounting support such as a 2" x 4" stud or a solid concrete wall, using mounting hardware that is appropriate for the surface on which you are mounting. DO NOT mount this unit directly to a stucco/drywall/wall board. If installing to a wood stud, use the lag screws provided and ensure the mounting plate is positioned on the centerline of the stud. If mounting onto a concrete, block, or brick wall, use an appropriate anchor for the type of wall on which you are installing the unit.

### 2.1.2 Grounding Instructions

The charging station must be implemented equipment grounding through a permanent wiring system or an equipment grounding conductor. Use a wire with a dedicated grounding wire and a ring terminal and connected to the equipment ground terminal block for grounding.

### 2.2 Tools & Parts Required for Installation

Tool	Size	Source of Supply	Remark			
Metric Hex Key (Allen) Wrenches	4mm & 5mm	Commercially Available	For Mounting Fasteners			
Phillips Screwdriver	#2 or similar	Commercially Available	For EVOREEL Cable Stop Adjustment & Plug Holder			
Torx Driver	T20	Commercially Available	For Charging Station Cover Screws and Lock Screw			
Torque Wrench	~ 30 lbf-in	Commercially Available	For tightening all charging station fasteners/screws			
Wire, Copper	8 AWG	Commercially Available	UL1015 (recommended) for Input Wiring Hardwire Connection			
Heat Shrink Tube x3	For 8 AWG wire	Commercially Available	For Input Wiring Hardwire Connection			
Terminal x3	For 8 AWG wire	Commercially Available	For Input Wiring Hardwire Connection			
Conduit & Fitting	1" NPT	Commercially Available	For Input Wiring Hardwire Connection			

Table 2	-1 Tools	& parts	required	for installation	n
	<b>T</b> 10013	a puits	requireu	ior motunation	

### 2.3 Input Wiring Connection (Optional for p/n: EVO30-101-002)

1. Choose the appropriate conduit and fitting in accordance with all applicable state, local and national electrical codes and standards. Please note the charging station knock-out size for the input wiring connection is 1" NPT.



Figure 2-7 Conduit

2. Using the appropriate tool, clamp the wire terminal to the copper wire. For non-insulated terminals, use heat shrink tube to cover the non-insulated portion of the terminal.



Figure 2-8 Copper terminal, heat shrink tube and copper wire.

- 3. Connecting the electrical wiring to the charging station.
  - 3-1. Place the Charging Station on a flat surface, front cover down with protection under the cover to avoid scratching damage to the cover.
  - 3-2. Remove the Charing Station front cover by loosening the (5) Torx screws at the rear of the charging station. Screw locations are shown in Figure 2-9, below:




Figure 2-9 Five Torx screw locations to remove the Charging Station Cover

- CAUTION: For model: <u>EVSE EVC4AA0C2B1A1</u> Non-networked charging station, the LED board is attached to the charging station front cover and the charging station circuit board. Use care to hold the front cover in place and not place force or strain on the wiring harness when the cover screws are removed. Failure to do so may result in damage to the charging station circuit board and/or LED harness, which is not covered under warranty.
- 3-3. With the (5) Torx screws loosened, hold the front cover in place and flip the charging station over on the flat surface so that the front cover is on top. Once this is completed, lift the charging station front cover and place to the right side of the charging station unit. Once this is completed, gently lift the charging station front cover and place to the right side of the charging station unit. Again, use care to not place force or strain on the wiring harness when the front cover screws are removed. Failure to do so may result in damage to the charging station circuit board and/or LED harness.
- 3-4. With the front cover placed to the side, insert the wire end passing through the conduit and insert them into the input wiring hole. (Use Red wire for L1, Black wire for L2, Green-yellow wire for G). Attach the copper wire on the corresponding terminal block. Use the following wire and torque force when connecting to input terminal block, using conductor type other than RHH, RHW and RHW-2 with outer covering.

Model	Terminal	Conductor	Screw	Rating	То	rque
EVOCHARGE EVSE	L1, L2, G	8 AWG	M4	90C, copper wire	16 kgf.cm	13.88 lbf-in




Figure 2-10 Input wiring

WARNING: To reduce the risk of fire, connect only to a circuit provided with the appropriate amperes minimum branch circuit overcurrent protection in accordance with the National Electrical Code, ANSI/NFPA 70, and the Canadian Electrical Code, Part I, C22.1.

Model	Current Setting	Circuit Rating Requirement
EVOCHARGE EVSE	30A	40A or greater

- 4. Once the input wiring and conduit are connected, reassemble the charging station.
  - 4-1. Reinstall the charging station font cover using the following torque force to secure the (5) Torx screws:

Screw	Torque		
M4	16 kgf.cm	13.88 lbf-in	

### 2.4 Installation Steps

- 1. First, secure the charging station mounting bracket to the wall or other suitable structure with appropriate mounting screws. If installing to a wall, ensure the screws are anchored into a suitable wall stud.
- 2. Follow applicable accessibility requirements for the mounting position. The unit shall be mounted at a sufficient height from ground such that the height of the storage means for the coupling device is located between 24 inches (0.6 m) and 48 inches (1.2 m) from ground per NEC Article 625.
- 3. The mounting bracket has ten screw holes to support attachment to multiple mounting surfaces. For most installation, including attached the charging station to a single wall stud, only two screws will be used to attach the mounting bracket. In this case, the screws should pass (install) through the middle two vertical screw holes of the mounting bracket as shown in Figures 2-3 & 2-4.




Figure 2-3 Installing the mounting bracket



Mounting Screw Recommendations:

- a. For finished walls supported by wood studs, use 1/4" or M6 tapping screws. (Supplied)
- b. For masonry walls, use M6 mechanical screws. (Commercially available)
- c. Use following torque force:

Screw	Torque	
M6	50 kgf.cm	43.4 lb-in
1/4"	50 kgf.cm	43.4 lb-in

- 4. Next, install the EVOREEL to a suitable mounting structure/surface. As previously noted, the charging station (EVOREEL and EVSE box) must be anchored into a mounting support such as a 2" x 4" stud or a solid concrete wall, using mounting hardware that is appropriate for the surface on which you are mounting. DO NOT mount this unit directly to a stucco/drywall/wall board. If installing to a wood stud, use the lag screws provided and ensure the mounting plate is positioned on the centerline of the stud. If mounting onto a concrete, block, or brick wall, use an appropriate anchor for the type of wall on which you are installing the unit.
- 5. Once the EVOREEL unit is installed, install the EVSE box onto its mounting bracket and secure the lock screw as shown in Figure 2-5.
  - 5-1. Tighten the installed M4 screw and screw washer to fix charging station on mounting bracket.
  - 5-2. Use following torque force:

Screw	То	rque
M4	16 kgf.cm	13.88 lbf-in




Figure 2-5 Screw locking position

6. Once installed, adjust the EVOREEL cable guide bracket assembly to allow the cable guide and EV Charging Cable/Plug assembly to point/position in the downward direction as shown in Figure 2-6. The roller guide arm can be adjusted by removing the 5/16 hex head bolt and lock washer and rotating the bracket to the downward position. Once repositioned, reinstall the 5/16" hex head bolt and lock washer. (Note: If required for local building codes, an optional Safety Chain Mounting Hole is on the EVOREEL main bracket as shown in Figure 2-6).




Figure 2-6 EVOREEL Cable Guide Bracket Adjustment

7. After the EVOREEL cable guide brackets are adjusted, adjust the Cable Stop to extend the Charging Plug/Connector to the desire height (Note: For public installations, to meet ADA reach requirements, the Charging Plug/Connector height should not exceed 48 inches from the Ground when the cable is fully retracted). Referring to Figure 2-7, adjust the Cable Stop by loosening the Cable Stop Screws (Step 1), moving the cable stop to the desired position (Step 2) and then fastening the screws to secure the Cable Stop (Step 3).






Figure 2-7 Cable Stop Adjustment


### 2.5 Install the Plug and Cable Holder

1. Separate the holder from hook.





2. The Plug Holder can be installed at any location near. Once the holder installation location is determined, install the holder bracket with the provided screws (x2).





3. Position the plastic holder insert face up and install into the holder bracket.




Figure 2-10 Secure the holder

4. Next, rotate the holder insert down.




Figure 2-11 Rotate the holder

5. With the holder insert in the down position, tighten the (2) lock/set Phillips screws located at the top of the plastic holder component until snug (do not overtighten). The screws ensure that the plastic holder component remains secured to the holder bracket. The holder can now be used to store the EV plug.




Figure 2-22 Lock screws

### 2.6 Charging Status Indicators

Table 2-2 Charging status indicators

LED Indicator	Description	ng status indicators Definition
	Not illuminated	Power Off
	Green Steady	Ready
	Green Flashing	Flashing green (Fast): Authorized, waiting for EV to initiate charge event. Flashing green (Slow): Suspend (Occupying)
	Blue Flashing	Flashing blue (Slow): Charging
	Red Steady	Unrecoverable Fault
	Red Flashing	Recoverable Fault
	Yellow Steady	Out of Service
	Yellow Flashing	Booting / Firmware Upgrade in process

\*Note: In the instance the "Red Steady" or "Red Flashing" Fault light remains, it is recommended that you:

- Unplug the charging Connector from your EV
- Turn off the power to the Charging Station by switching the upstream circuit breaker to the "OFF" position
- With the circuit breaker in the "OFF" position, wait 1-2 minutes and then switch the upstream circuit breaker back to the "ON" position
- Confirm the Fault light is no longer present. If the Fault light remains, please contact EVOCHARGE.

### 2.7 Charging your Electric Vehicle (EV)

The EVOCHARGE iEVSE Plus supports both "Authorized" (Access Control) operation as well as "Plug and Charge" operation.

When the EVOCHARGE iEVSE Plus is configured to require Authorization, the EVSE must first authorize the operation (via RFID card, mobile app, etc.). The EVSE will only supply energy after authorization.

### 2.7.1 Plug and Charge

This setting must be activated using the web portal – this can be used in instances where access control or payment are not required by the charging station owner.

- 1. Insert the charging plug into the EV
- 2. Charging session will automatically commence





Figure 2-3 Connect the charging plug to the EV

### 2.7.2 Online Authorization

Authorization via RFID Card and/or mobile app.




### 2.7.3 RFID Card Authorization Local and Offline Authorization

Description:

Synchronized with the Central System when EVSE is Online.

- To improve the experience for users, the EVOCHARGE iEVSE Plus can be programmed to allow local authorization when EVSE is *offline or not connected to a network*. This also supports faster authorization response time in the instance the communication between EVOCHARGE iEVSE Plus and Central System (Network) is slow to respond.
  - 1. Insert the charging plug into the EV
  - 2. Swipe RFID card
  - 3. Wait for authorization
  - 4. Charging session will automatically commence once authorized



### 2.8 Stop Charging

- 1. Simply unplug the charging station connector from the EV at any time (once the connector button is depressed, the charging session terminates immediately).
- 2. Return the connector to the holder.

### 2.8.1 Self-Monitoring and Recovery (Auto Restart)

When a charging session is interrupted due to a temporary error condition, the charging station will automatically restart charging when the cause of the temporary error condition returns to normal. The status indicator lights remain flashing RED until the error condition is resolved.

- Temporary error conditions include: Over Current, Over Voltage, Under Voltage, and Over Temperature.
- For Over Current (OC) conditions: The charging session will be stop while OC occurs. After recovery from OC for 30 seconds, the charging station will automatically restart charging for three times.
- When charging session stopped due to CCID trip, the charging station will try to restart after 15 minutes for 3 times.

### 2.8.2 Power Outage Recovery

When power resumes after an outage, the charging station restarts automatically with a delay ranging from 120 to 720 seconds. The delay is designed to avoid impacting the utility grid when multiple charging stations are in the same area attempting to resume charging simultaneously.

Please refer to STOP CHARGING section for more information.

### 2.9 General Product Care and Use Information

The exterior of the charging station is designed to be waterproof and dust proof (NEMA 4 Outdoor Rated). However, periodic cleaning may be required, depending on local conditions. To ensure proper maintenance of the charging station, follow these guidelines:

- To avoid damaging the finish of the products, only use an automotive grade soft cleaning cloth and if required a mild soap and water mixture to remove accumulation of dirt and dust. Do not use cleaning solvents to clean any of the product components. Despite the water resistance of the enclosure, when cleaning it is preferred to not direct streams of water at the unit – clean with a water damp, automotive grade soft cleaning cloth.
- Make sure the charging connector is put back in the holder after charging to avoid damage.
- Ensure the power cable is stored on the charging station after use to avoid damage.
- If the power cable or the charging connector is damaged, turn off the charging station supply circuit breaker, do not use the charging station, and please contact EVOCHARGE Customer Support for replacement parts.
- When moving or lifting the unit, always grasp and carry by the charging station plastic body. Never attempt to lift, move, or carry the unit by any of the electrical cables. Improper handling may cause damage to the unit.

For Additional Products and Field Support visit <u>www.phillpsandtemro.com</u> or contact us at 1-800-328-6108.